

Quality Industries

Foodservice

156 East Main St. Auburntown, TN 37016

1-615-306-2883

edschultz@bucketofsteam.com



**Quality
Industries**
FOODSERVICE
BY STAINLESS



Fridge/Freezer User Manual

Thank you for your business!

We trust you will find this new Fridge/Freezer to be quiet, efficient,
and durable

**Please return this completed page. The owner is required to
return this product registration information immediately.**

The model and serial numbers are stamped on the nameplate
located next to the machine's controls. Please print clearly.

-----Second Fold Line-----

Place
stamp
here

Quality Industries Foodservice
156 East Main St. Auburntown, TN 37016

-----First Fold Line-----Seal with tape-----Do not staple-----

Store Name: _____ Store I.D.#: _____

Address: _____

City: _____ State/Province/Region: _____

Country: _____ Postal Code: _____

Telephone: _____ Fax: _____

Store Owner: _____

Model: _____

Serial Number(s): _____

This page intentionally left blank.

Quality Industries

Foodservice

156 East Main St. Auburntown, TN 37016

1-615-306-2883

edschultz@bucketofsteam.com



Fridge/Freezer

Operation, Maintenance, and Warranty

Read this manual thoroughly before operating machine. The model and serial numbers are on the data plate mounted on the machine. Record the model and serial numbers below.

Refer to these numbers in any correspondence with Quality Industries Foodservice.

Model _____

Serial Number(s) _____

Note: All procedures listed on these pages are general use guidelines. Please refer to your company procedures for exact instructions.

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before operating. When using electrical appliances, basic safety precautions must be followed. Use this appliance only for its intended use as described in this manual. Verify that appliance is properly installed and electrically grounded by a qualified technician in accordance with local electrical codes. Do not attempt to repair or replace electrical components. A qualified technician should complete all servicing to these components. Before performing any service, disconnect the machine's power supply. Never wear loose-fitting or hanging garments while using any appliance. Ties, necklaces, etc. may catch on moving parts...possibly causing injury.

CAUTION - Risk of fire and/or electrical shock. Replace only with manufacturer's cord set.

DO NOT SPRAY MACHINE WITH WATER

Machine is designed to shed water & dust; however, **IT IS NOT WATERPROOF.**

Quality Industries Foodservice

156 East Main St. Auburntown, TN 37016

1-615-306-2883

edschultz@bucketofsteam.com



Table Of Contents

Important Safety Instructions

Operations

Product Specifications

Problem Solving Guide

Terms and Conditions

Contact Us

Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury when using this fridge/freezer, follow these basic safety precautions:

1. Read all instructions carefully before operating the fridge/freezer.
2. Do not store flammable materials such as gasoline or other volatile chemicals inside the unit.
3. Electrical Safety:
 - Plug the unit directly into a properly grounded 120V outlet.
 - Avoid using extension cords or power strips.
4. Keep the unit away from heat sources, such as ovens or direct sunlight, to prevent overworking the compressor.
5. Ensure proper ventilation by keeping at least 4 inches of clearance around the unit.
6. Do not overload the shelves beyond their weight limit, as this may cause damage or obstruct airflow.
7. Keep the doors closed as much as possible to maintain efficiency.
8. Unplug the unit during maintenance or when not in use for extended periods.
9. Use only manufacturer-recommended replacement parts and accessories.
10. Do not touch cold surfaces with wet hands to avoid injury.
11. Regularly check the power cord for signs of damage. Do not use the unit if the cord is frayed or damaged.
12. Monitor the internal temperature regularly to ensure it remains within the desired range.

SAVE THESE INSTRUCTIONS

Operation

Initial Setup

- **Unpack the Unit:** Carefully remove all packaging materials, ensuring no damage to the fridge/freezer.
- **Placement:** Position the unit on a flat, stable surface with at least 4 inches of clearance around the sides and back for proper ventilation. The unit is freestanding and comes with casters for easy movement.
- **Electrical Connection:** Plug the unit into a grounded 120V electrical outlet. Ensure the outlet can handle 5 amps without overloading the circuit. Avoid using extension cords or power strips.

Temperature Settings

- **Initial Temperature:** Upon plugging in, set the temperature using the thermostat inside the unit. The recommended temperature range is between 25°F and 45°F.
- **Adjusting Temperature:** Use the control panel to adjust the temperature settings as needed for either refrigeration or freezing.

Loading the Fridge/Freezer

- **Shelving:** The unit comes with 8 shelves. Arrange the shelves as necessary to fit your storage needs. Allow airflow between items to maintain even cooling.
- **Door Use:** Ensure that the double swing doors are properly closed after each use to maintain temperature efficiency.

Operating the Fridge/Freezer

- **Dual Operation:** The fridge/freezer is designed to operate within the specified temperature range (25°F - 45°F). Monitor the internal temperature regularly using the built-in thermometer.
- **Use the Casters:** For easy mobility, the unit is equipped with casters, allowing it to be moved when necessary. Lock the casters in place once positioned to prevent accidental movement.

Shutting Down

- **Turning Off:** To turn off the unit, adjust the thermostat to the "OFF" position and unplug the unit from the electrical outlet.
- **Unplugging:** If the unit will not be in use for an extended period, ensure it is unplugged and the doors are left slightly open to prevent odor buildup.

Cleaning and Maintenance

- **Interior Cleaning:** Regularly clean the interior surfaces using a damp cloth and mild detergent. Avoid using harsh chemicals or abrasive materials that may damage the stainless steel.
- **Exterior Cleaning:** Wipe the exterior with a soft cloth to maintain the appearance of the brushed stainless steel finish.
- **Condenser Maintenance:** Clean the condenser coils every three months to maintain efficient cooling performance.

Product Specifications

Fridge/Freezer, Double Straight Door (Model 5005248)

- Shipping Weight: 541 lb. (245.5 kg)
- Exterior Dimensions:
 - Width: 47 inches (1,194 mm)
 - Depth: 33 3/4 inches (857 mm)
 - Height: 84 inches (2,134 mm)
- Interior Dimensions:
 - Width: 44 inches (1,118 mm)
 - Depth: 25 7/8 inches (657 mm)
 - Height: 61 5/8 inches (1,565 mm)
- Capacity: 44 cu. ft.
- Voltage: 120V
- Amps: 5 Amps
- Hertz: 50/60 Hz
- Temperature Range: 25°F - 45°F
- Color: Silver (Stainless Steel)
- Number of Doors: 2 (Swing style, solid)
- Number of Shelves: 8 adjustable shelves
- Installation Type: Freestanding with casters



Problem-Solving Guide

1. Unit Does Not Cool Properly

Possible Causes:

- The temperature control is not set correctly.
- The doors are not fully closed, or the door seals are damaged.
- The condenser coils are dirty or blocked.

Solutions:

- Adjust the thermostat to the appropriate setting for refrigeration or freezing.
- Ensure both doors are closed securely, and inspect the door seals for wear or damage.
- Clean the condenser coils to improve airflow and cooling efficiency.

2. Unusual Noise from the Unit

Possible Causes:

- The fridge/freezer is not level.
- Internal components like the fan or motor may be obstructed or malfunctioning.

Solutions:

- Ensure the unit is placed on a flat, level surface.
- Inspect the fan and motor areas for obstructions, and if the noise persists, contact a service technician.

3. Excessive Condensation Inside the Unit

Possible Causes:

- High humidity or the door is frequently left open.
- The door seals may be damaged or not sealing properly.

Solutions:

- Reduce door openings and ensure the door is closed tightly after each use.
- Check the door seals for damage and replace them if necessary.

4. Power Outage or Unit Stops Running

Possible Causes:

- The unit is not plugged in securely, or the outlet is not functioning.
- The circuit breaker has tripped.

Solutions:

- Ensure the unit is plugged in securely and that the outlet is working.
- Check the circuit breaker and reset it if necessary.

5. Frost Buildup Inside the Unit

Possible Causes:

- The door is not closing properly, allowing moisture to enter.
- The temperature setting is too low.

Solutions:

- Ensure the doors are fully closed and the seals are intact.
- Raise the temperature slightly to prevent frost accumulation.

Terms and Conditions

DAMAGED SHIPMENTS

In the event of damaged shipments, whether the damage is apparent upon delivery or concealed and discovered after unpacking, the customer must notify the carrier immediately. Filing a claim with the carrier is the customer's responsibility, as Quality Industries Foodservice assumes no liability for goods damaged after they have left our facility. Once goods ship from our dock, the responsibility for handling damage claims rests with the customer.

RETURNS

No product returns will be accepted without prior written approval from Quality Industries Foodservice. All returns must be shipped freight prepaid by the customer and may be subject to handling or restocking fees.

WARRANTY

Quality Industries Foodservice warrants that the Fridge/Freezer is free from original defects in both workmanship and materials, provided the product has been properly stored, installed, serviced, maintained, and operated. This warranty is extended solely to the original purchaser and covers the mechanical and electrical components that make up the drive system of the machine.

This warranty includes full replacement of defective components as well as labor coverage. The warranty period begins on the earlier of the product's initial use or 60 days from the shipment date from our factory. The parts warranty is valid for 12 months, while labor is covered for a period of 90 days.

To activate this warranty, the end user must register ownership of the product by returning the warranty card included with the machine. Failure to register the product immediately will void the warranty.

In the event of a performance issue, the end user must notify Quality Industries Foodservice, providing the model and serial number of the machine. Quality personnel will assist in diagnosing the issue, arrange for the shipment of replacement components if needed, and authorize a service agency if required. Replacement parts will be shipped at no cost via the least expensive method, provided the defective part is returned within two weeks (if requested by Quality Industries Foodservice). The company reserves the right to test and evaluate the returned part to determine if the failure is covered under warranty. If defective parts are not returned within the specified time, or if the issue is not covered by the warranty, the customer will be invoiced for the replacement component, shipping costs, and labor charges, if applicable.

Quality Industries Foodservice assumes no responsibility for any costs associated with the removal or installation of replacement parts, including but not limited to travel time, fuel charges, or labor. We are not liable for any other costs or damages arising from product nonperformance, including shipping costs for returning defective products or components. The buyer assumes all risks and liabilities associated with the use of the product.

This warranty does not apply to products that have been misused, subjected to negligence or accidental damage, or altered/repared in a manner that affects the product's performance or reliability. Peripheral items such as lugs, plugs, pans, pots, baskets, or other accessories that may be sold as part of a package with the Fridge/Freezer are not covered by this warranty.

Contact Us

For any questions regarding the operation, maintenance, or warranty of your Quality Industries Foodservice Fridge/Freezer, please feel free to contact us. Our dedicated customer support team is available to assist you with troubleshooting, replacement parts, and service requests. You can reach us via phone, email, or through our website's contact form. We are committed to providing prompt and reliable assistance to ensure your equipment operates at peak performance.

- **Phone**



+1 615-306-2883

- **Message**



edschultz@bucketofsteam.com

- **Website**



qualitybystainless.com

- **Address**



156 East Main St. Auburntown, TN 37016